

QUICK REFERENCE

PROFESSIONAL FLOW LIMITER MK2

1. Connect the Professional Flow Limiter Mk2 to the fitting of your cylinder valve.
2. Connect your analyzer to the gas sampling nozzle via the Connection hose #8009 (not included).
3. Slowly open the cylinder valve.
4. Turn the gas sampling nozzle counterclockwise to initiate gas flow, if the nozzle was completely closed from the last use.
5. Take your measurements.
6. Close the cylinder valve.
7. Turn the gas sampling nozzle clockwise to vent the remaining gas from the device.*
8. Disconnect the device from cylinder valve.

*It is not necessary to turn the nozzle to a hard stop, doing so will completely halt flow if desired



DIVESOFT